



Apply a bead of mastic in grooves  
before clipping in the bottom cladding