

Glass Removal

In the event that a pane of glass should shatter or the balustrade system is to be changed due to a change of design of building ETC. Then the following processes should be carried in order to do the job effectively and efficiently.

1. The working area should be made easily accessible and clean. PPE should be worn on site of removal, as if the glass hasn't shattered there is a possibility of it doing so on removal.
2. A wedge extraction tool should be at hand to remove the wedges from the channel these can either be hired or purchased from Purevista. As the picture below shows the removal tool grips around the wings of the aluminium wedges.



3. After removing the wedges the glass if broken should be cleaned out of the channel using either a brush or a Hoover as this will ensure that there are no bits of broken glass remaining, making re-installation of new glass easier. However if the channel is to be removed then this will give access to the bolt fixings in the channel.

Should you require any further help please contact us on the below.